

Long Haul Expedition Tuckunder Spraycover Installation Instructions

Greetings Long Haul Folding Kayak owner / Klepper owner!

Here are basic instructions on how to use and install your new Expedition Long Haul Tuckunder Spraycover.

1. Inflate your air-sponsons to approximately one half maximum inflation.
2. Place the spraycover over the mast bracket with the small cotton webbing tucked under the front of the mast bracket.
3. Pull the spraycover to the rear of the cockpit and hook the grommets over the two screws that are attached to the rear coaming piece.
4. Tuck the edge of spraycover between the coaming and the deck material pulling the spraycover tight over the coaming as you tuck it in.
5. Pass your rudder cables through the two holes in the rear coaming piece then snap the spraycover snaps around the cables.
6. Inflate the air-sponsons to maximum pressure. This will secure the spraycover to the kayak.
7. Loop the skirts around the cockpit rings.
8. The cockpit rings are made with cotton deck material and rubber. Remember to always store your spraycover dry.
9. Preventative maintenance includes using: 303-fabric protectant on the cotton material around the rings and fabric areas and using 303-rubber protectant on the non-fabric areas.

Happy Paddling,
Mark Eckhart

If you have any questions please feel free to contact us.

Long Haul Folding Kayaks, 16869 Ward Creek Road, Cedaredge, CO. 81413, USA
Phone: 970-856-3662, Fax: 970-856-3663