

DIRECTIONS FOR APPLYING VINYL CEMENT TO SPONSON TUBING

1. Sand hose, then apply vinyl cement.
2. Immediately following the application of cement, push the hose onto the sponson sack hose, as far as possible.
3. Next, apply twist off valves to the hose.
4. Cut hose to desired length.
5. Follow same instructions for application of twist off valves.

Please contact Long Haul Folding Kayaks if you have any further question.

Thank you,

Long Haul Folding Kayaks Staff

Long Haul Folding Kayaks, 16869 Ward Creek Road, Cedaredge, CO. 81413, USA
Phone: 970-856-3662, Fax: 970-856-3663

Website: www.LONGHAULFOLDINGKAYAKS.COM